

# SunRise Apollo HS Upgrade Kits

Capitalise on your investment! Upgrade your existing SunRise scanner to an Apollo HS specification, in doing so harness all the power, speed and versatility of the latest technology, but at a fraction of the cost of buying a new system.

Scanner	Speed pages/min	Power watts	OS version
<b>S2000,S2000+</b>	175 → 380	400 → 150	Win 2000 → Win10
<b>S2500</b>	205 → 380	350 → 150	XP → Win10
<b>RapidScan</b>	300 → 380	300 → 150	XP → Win10
<b>Speed/TurboScan</b>	200 → 380	250 → 150	XP → Win10
<b>Apollo</b>	380 → 380	150 → 150	Win7 → Win10

Apollo upgrade kits convert old Sunrise Scanners to be the equivalent of latest Apollo HS scanners. Older scanners used Windows 2000, XP which is replaced by Win 7. The cooling system in older scanners used several internal fans, these have been eliminated, so the scanner is now virtually silent, and uses less power.

## Hardware

Your existing base chassis is used to make your new Apollo system.

A new camera insert supports the new Apollo HS camera

A new rear plate with outside exhausting power supply mount replaces the old rear plate.

A new Drive Bay and USB panel are added to the front of the scanner

Upgrades can be done on-site or at the factory.

## Electronics

New PCI Image capture card replaces X19

New Motherboard I-Core 7, 4GB, onboard 500GB SSHD

LED Lamp replaces Halogen lamp Box

DVD / 2.5" dual drive bays 2TB SSHD

600w Pwr Supply replaces old one.

Existing X20 motion control card, and X19 PCI bus interface cards are used

Lower power, faster computing.

## Software

Use improved MS Windows 10 user interface features

Scanflo 5.0 Professional Premier and Virtual Scan Software are included in the upgrade.

Live scan with Professional without need for training

Learn new features of Scanflo Premier and Virtual Scan in a couple days. Customer says the new layout is easier to use, and with VS tackle really difficult films.

## SunRise Imaging, Inc.

1813 E Dyer Road # 410  
Santa Ana CA 92705  
Tel +1 949 252-3003  
sales@sunriseimaging.com  
www.sunriseimaging.com

## SunRise Imaging (EMEA) Ltd.

SBC House, Restmor Way  
Wallington, Surry  
United Kingdom SM6 7AH  
Tel +44 208 255 2011  
Sales@sunriseimaging.co.uk

