

# SunRise Apollo HS Upgrade Kits

- Stay competitive
- Lower operating costs
- Reduce scan time
- Lower support costs
- Simplify scan tasks

*Invest in your Sunrise Scanner with an upgrade. **Scan faster** and connect directly with Networks with a supported version of Windows, and be backed by Sunrise support service.*

Scanner	Speed pages/min	Power watts	Ver	OS version
<b>S2000,S2000+</b>	175 → 380	400 → 150	4.0	Win 2000 → Win10
<b>S2500</b>	205 → 380	350 → 150	1.04	XP → Win10
<b>RapidScan</b>	300 → 380	300 → 150	3.11	XP → Win10
<b>Speed/TurboScan</b>	200 → 380	250 → 150	3.11	XP → Win10
<b>Apollo</b>	380 → 380	150 → 150	4.x	Win7 → Win10

Apollo upgrade kits convert old Sunrise Scanners to the equivalent of latest Apollo HS scanners. Older scanners used Windows 2000, XP which is replaced by Win 10. The cooling system in older scanners used several internal fans, these have been eliminated, so the scanner is now virtually silent, and uses less power.

## Hardware

Your existing base chassis is used to make your new Apollo system.

A new camera insert supports the new Apollo HS camera

A new rear plate with outside exhausting power supply mount replaces the old rear plate.

A new Drive Bay and USB panel are added to the front of the scanner

Upgrades can be done on-site or at the factory.

## Electronics

New PCI Image capture card replaces X15

New Motherboard I-Core 7, 4GB, onboard 500GB SSHD

LED Lamp replaces Halogen lamp Box

DVD / 2.5" dual drive bays 2TB SSHD

600w Pwr Supply replaces old one.

Existing X20 motion control card, and X19 PCI bus interface cards are used

Lower power, faster computing.

## Software

Use improved MS Windows 10 user interface features

Scanflo 5.0 Professional & Premier and Virtual Scan Software are included in the upgrade.

Live scan with Professional without need for training

Learn new features of Scanflo Premier and Virtual Scan in a couple days. Customer says the new layout is easier to use, and with VS tackle really difficult films.

## SunRise Imaging, Inc.

1813 E Dyer Road # 410  
Santa Ana CA 92705  
Tel +1 949 252-3003  
sales@sunriseimaging.com  
www.sunriseimaging.com

## SunRise Imaging (EMEA) Ltd.

SBC House, Restmor Way  
Wallington, Surry  
United Kingdom SM6 7AH  
Tel +44 208 255 2011  
Sales@sunriseimaging.co.uk

